



# ASSEMBLY



## BALL BEARING REPLACEMENT FOR DISKS

1. The ball bearing hub components on your 10, 14 or 16-inch disks should last several years with proper use.
2. These disks and the machine they are used on are intended to be used in loose soil.
3. If you experience premature bearing problems, either the machine is not adjusted correctly or the tillage is not adequate.
4. We have other options if you need to disk firm soil.